



# ITEM SHEET

## CORDLESS PHONE BATTERIES

Battery Solutions, Inc.  
2301 Avenue B  
Lubbock, Texas 79404  
(806) 771-3777  
sales@batterysolutionsinc.com  
[www.batterysolutionsinc.com](http://www.batterysolutionsinc.com)

## CORDLESS PHONE BATTERIES

<u>MODEL #</u>	<u>DESCRIPTION</u>	<u>CHEM.</u>	<u>VOLTS</u>	<u>AMPS</u>
CPB-400	1X3AA	Ni-CD	3.6	900mAh
CPB-400B	1X3AA/B	Ni-CD	3.6	900mAh
CPH-400B	Use CPH-454			
CPB-400C	1X3AA/C	Ni-CD	3.6	900mAh
CPB-400D	1X3AA/D	Ni-CD	3.6	900mAh
CPH-400D	Use CPH-482D			
CPB-400J	1X3AA/J	Ni-CD	3.6	700mAh
CPH-400J	1X3AA/J		3.6	1500mAh
CPB-400K	1X3AA/K	Ni-CD	3.6	700mAh
CPB-400X	1X3AA/X	Ni-CD	3.6	900mAh
CPB-401	3/280 (CLOVER)	Ni-CD	3.6	280mAh
CPB-401B	3/280/B (CLOVER)	Ni-CD	3.6	280mAh
CPB-401X	3/280/X (CLOVER)	Ni-CD	3.6	280mAh
CPB-402L	1X4AA/L	Ni-CD	4.8	700mAh
CPB-403	1X3-2/3AA	Ni-CD	3.6	400mAh
CPB-403B	1X3-2/3AA/B	Ni-CD	3.6	400mAh
CPB-403C	1X3-2/3AA/C	Ni-CD	3.6	300mAh
CPH-403C	1X3-2/3AA/C	Ni-MH	3.6	750mAh
CPB-403D	1X3-2/3AA/D	Ni-CD	3.6	400mAh
CPH-403D	1X3-2/3AA/D	Ni-MH	3.6	750mAh
CPB-403J	1X3-2/3AA/J	Ni-CD	3.6	400mAh
CPH-403J	1X3-2/3AA/J	Ni-MH	3.6	750mAh
CPB-403M	1X3-2/3AA/M (DISCONTINUED 04/10)	Ni-CD	3.6	400mAh
CPB-403M3	1X3-2/3AA/M3	Ni-CD	3.6	300mAh
CPB-403P3	1X3-2/3AA/P3	Ni-CD	3.6	300mAh
CPB-404B	3/280/B (STACK)	Ni-CD	3.6	280mAh
CPB-404C	3/280/C (STACK)	Ni-CD	3.6	280mAh
CPB-404L3	3/280/L3 (STACK)	Ni-CD	3.6	280mAh
CPB-404M	3/280/M (STACK)	Ni-CD	3.6	280mAh
CPB-404P	3/280/P (STACK)	Ni-CD	3.6	280mAh
CPB-404P3	3/280/P3 (STACK)	Ni-CD	3.6	280mAh
CPB-405C	3/170/C (2 ON 1)	Ni-CD	3.6	170mAh
CPB-405D	3/170 /D (2 ON 1)	Ni-CD	3.6	170mAh
CPB-405G	3/170/G (2 ON 1)	Ni-CD	3.6	170mAh
CPB-405M	3/170/M (2 ON 1)	Ni-CD	3.6	170mAh
CPB-407	3-2/3AA (TRIANGLE)	Ni-CD	3.6	300mAh
CPB-407B	3-2/3AA/B (TRIANGLE)	Ni-CD	3.6	300mAh
CPB-408	2X2-2/3AA (DIAG)	Ni-CD	4.8	300mAh
CPB-409M	1X4-2/3AA/M	Ni-CD	4.8	300mAh
CPB-413	4/280 (STACK)	Ni-CD	4.8	280mAh
CPH-429	SONY BP-T40	Ni-MH	3.6	650mAh
CPB-430	SONY NP-100	Ni-CD	3.6	600mAh
CPB-431	PANASONIC KX-A39	Ni-CD	4.8	600mAh
CPB-432C	1X5AA/C	Ni-CD	6.0	850mAh
CPB-433B	1X2-2/3AA/B	Ni-CD	2.4	300mAh
CPB-433C	1X2-2/3AA/C	Ni-CD	2.4	300mAh
CPB-433D	1X2-2/3AA/D	Ni-CD	2.4	300mAh
CPB-433H	1X2-2/3AA/H	Ni-CD	2.4	300mAh
CPB-434	PANASONIC KX-A45	Ni-CD	4.8	600mAh
CPB-435	PANASONIC P-P543, TYPE 43	Ni-CD	3.6	600mAh
CPB-436	PANASONIC P-P201, TYPE 5	Ni-CD	3.6	110mAh
CPB-437	PANASONIC P-P502, TYPE 6	Ni-CD	3.6	110mAh
CPB-438	UNIDEN EXP-901	Ni-CD	3.6	600mAh
CPB-442	PANASONIC P-P592, TYPE 92	Ni-CD	3.6	600mAh
CPH-442	PANASONIC P-P592, TYPE 92	Ni-MH	3.6	1300mAh
CPB-445	PANASONIC KX-A40	Ni-CD	4.8	600mAh
CPB-446C	1X3-2/3AF/C	Ni-CD	3.6	500mAh
CPB-446D	1X3-2/3AF/D	Ni-CD	3.6	600mAh
CPH-449	AT&T/LUCENT 3077	Ni-MH	6.0	700mAh
CPH-450B	1X3-2/3AAA/B	Ni-MH	3.6	350mAh
CPH-450C	1X3-2/3AAA/C	Ni-MH	3.6	350mAh
CPH-450J	1X3-2/3AAA/J	Ni-MH	3.6	350mAh

## CORDLESS PHONE BATTERIES (cont'd)

<b>MODEL#</b>	<b>DESCRIPTION</b>	<b>CHEM.</b>	<b>VOLTS</b>	<b>AMPS</b>
CPH-454	PANASONIC HHR-P505, TYPE 19	Ni-MH	3.6	1500mAh
CPB-456	AT&T/LUCENT 3091	Ni-CD	3.6	700mAh
CPB-457	GE BT-33	Ni-CD	3.6	720mAh
CPH-459	PANASONIC HHR-P401, TYPE 16	Ni-MH	3.6	1200mAh
CPB-461	AT&T/LUCENT 3094	Ni-CD	3.6	600mAh
CPB-462	SONY BP-T31	Ni-CD	3.6	600mAh
CPB-463	CIDCO CL980	Ni-CD	3.6	600mAh
CPH-463	CIDCO CL990	Ni-MH	3.6	1200mAh
CPH-464B	1X3AAA/B	Ni-MH	3.6	700mAh
CPH-464C	1X3AAA/C	Ni-MH	3.6	700mAh
CPH-464D	1X3AAA/D	Ni-MH	3.6	700mAh
CPH-464J	1X3AAA/J	Ni-MH	3.6	700mAh
CPH-464Q	CASIO PM-3201013	Ni-MH	3.6	700mAh
CPH-464Q3	UNIDEN BT-930	Ni-MH	3.6	700mAh
CPH-464Q3S	NORTEL NT7B65LD	Ni-MH	3.6	700mAh
CPH-464T	TELEMATRIX BATT-9600	Ni-MH	3.6	700mAh
CPH-464X	1X3AAA/X	Ni-MH	3.6	700mAh
CPH-464XR	1X3AAA/XR	Ni-MH	3.6	700mAh
CPB-466	UNIDEN BT-990/2499	Ni-CD	3.6	800mAh
CPH-467	AT&T/LUCENT 3430	Ni-MH	3.6	600mAh
CPB-469	AT&T/LUCENT 3500	Ni-CD	3.6	480mAh
CPH 470	V-TECH 80-4289-03-00	Ni-MH	3.6	600mAh
CPB-473C	1X3-1/2AA/C	Ni-CD	3.6	300mAh
CPB-474	SIEMENS MEGASET 940/950/960	Ni-CD	3.6	600mAh
CPB-475	ADARA CD03FA00600	Ni-CD	3.6	600mAh
CPB-478B	PANASONIC P-P507, TYPE 18	Ni-CD	7.2	700mAh
CPH-479B	PANASONIC HHR-P506A, TYPE 17	Ni-MH	2.4	1500mAh
CPB-479J	SONY BP-T50	Ni-CD	2.4	700mAh
CPH-479Z	PANASONIC HHR-P509, TYPE 20	Ni-MH	2.4	1500mAh
CPH-482D	AT&T 2414	Ni-MH	3.6	1500mAh
CPB-483	SONY BP-T23	Ni-CD	3.6	800mAh
CPH-483	SONY BP-T23	Ni-MH	3.6	1200mAh
CPH-485	PANASONIC HHR-P546A, TYPE 23	Ni-MH	2.4	1500mAh
CPB-486B	SONY BP-T38	Ni-CD	3.6	900mAh
CPB-487	PANASONIC P-P511, TYPE 24	Ni-CD	3.6	900mAh
CPH-487	PANASONIC HHR-P402, TYPE 30	Ni-MH	3.6	1200mAh
CPH-488B	UNIDEN BT-446	Ni-MH	3.6	800mAh
CPH-488C	1X3-5/4AAA/C (DISCONTINUED 01/10)	Ni-MH	3.6	800mAh
CPH-488D	1X3-5/4AAA/D	Ni-MH	3.6	800mAh
CPH-488J	1X3-5/4AAA/J	Ni-MH	3.6	800mAh
CPH-488Q3	1X3-5/4AAA/Q3	Ni-MH	3.6	800mAh
CPH-489	PANASONIC HHR-P513A, TYPE 27	Ni-MH	2.4	1500mAh
CPH-490	PANASONIC HHR-P103, TYPE 25	Ni-MH	3.6	700mAh
CPB-493C	1X3-4/5AA/C (DISCONTINUED 01/10)	Ni-CD	3.6	720mAh
CPH-495	CASIO PMP-3850, SLIDE-IN, 1X3AAA	Ni-MH	3.6	600mAh
CPH-496	PANASONIC HHR-P104, TYPE 29	Ni-MH	3.6	850mAh
CPH-498	AT&T/LUCENT/AVAYA 2C1	Ni-MH	4.8	800mAh
CPH-499	AT&T/LUCENT/AVAYA 2C2	Ni-MH	4.8	2150mAh
CPH-502	AVAYA/SPECTRALINK PTS360	Ni-MH	4.8	700mAh
CPH-503	UNIDEN EXP-9580	Ni-MH	4.8	700mAh
CPH-504PR	1X3-SAAA/PR	Ni-MH	3.6	450mAh
CPH-505	AT&T 2419, 2420, 1X3AAA W/PULL TAB	Ni-MH	3.6	700mAh
CPH-506	AVAYA 3204-EBS, 700281363	Ni-MH	3.6	800mAh
CPH-506-1.8	AVAYA 3204-EBY, 108586553	Ni-MH	3.6	1800mAh
CPL-507Q	UNIDEN BT-925	Li-Ion	3.6	720mAh
CPL-507Q3	UNIDEN BT-0001	Li-Ion	3.6	720mAh
CPH-508	PANASONIC HHR-P105, TYPE 31	Ni-MH	2.4	850mAh
CPL-509	UNIDEN BT-0002	Li-Ion	3.7	980mAh
CPH-510	UNIDEN BT-0003	Ni-MH	3.6	800mAh
CPH-511	NORTEL C3050, C3060	Ni-MH	3.6	750mAh
CPP-512Q	PLANTRONICS 64327-01	Li-Pol	3.7	230mAh
CPH-513	NORTEL T7406, M7410, NTAB9682	Ni-MH	3.6	1400mAh

LETTER SUFFIX INDICATES CONNECTOR. SEE BACK PAGE FOR CROSS-REFERENCE.

# CORDLESS PHONE BATTERIES (cont'd)

MODEL #	DESCRIPTION	CHEM.	VOLTS	AMPS
CPH-514	PANASONIC HHR-P107, TYPE 35	Ni-MH	3.6	700mAh
CPH-515B	UNIDEN BT-1008, BT-1016	Ni-MH	2.4	750mAh
CPH-515D	1X2AAA/D	Ni-MH	2.4	750mAh
CPH-515J	AMERICAN TELECOM LH070-3A43C2BRML1P	Ni-MH	2.4	750mAh
CPH-516B	UNIDEN BT-1002	Ni-MH	2.4	800mAh
CPH-517J	VTECH 89-1333-01-00, BT5632/BT5872	Ni-MH	3.6	500mAh
CPH-518D	VTECH 89-1337-00-00, BT18443/BT28443	Ni-MH	2.4	500mAh
CPP-519ZR	G.E. 5-2682	Li-Pol	3.7	500mAh
CPP-519Z3	G.E. 5-2707	Li-Pol	3.7	500mAh
CPH-520D3	G.E./RCA 5-2699	Ni-MH	3.6	2000mAh
CPH-521	SENNHEISER BA90	Ni-MH	2.4	80mAh
CPH-522	SENNHEISER BA191	Ni-MH	2.4	80mAh
CPP-523	SENNHEISER BA300	Li-Pol	3.6	140mAh
CPL-524Z3	G.E./RCA 5-2762	Li-Ion	3.6	500mAh
CPP-524Z3	G.E./RCA 5-2770	Li-Pol	3.7	500mAh
CPH-525	NORTEL T7406E, NT8B45AN	Ni-MH	3.6	900mAh
CPH-526	NORTEL 2211, AVAYA/SPECTRALINK BPX100	Ni-MH	3.6	750mAh
CPH-527QR	AASTRA 480ICT, CM-16	Ni-MH	3.6	550mAh
CPH-528	AT&T ID-282H, ID-2820	Ni-MH	3.6	650mAh
CPP-529Z	AT&T BT191545	Li-Pol	3.7	250mAh
CPH-530	CLARITY C4220, C4230	Ni-MH	3.6	800mAh
CPP-531	SENNHEISER BW900	Li-Pol	3.7	170mAh
NMH-2/AA	RECHARGEABLE AA BATTERIES - 2 PER	Ni-MH	1.2	2600mAh
NMH-2/AAA	RECHARGEABLE AAA BATTERIES - 2 PER	Ni-MH	1.2	900mAh

## CONNECTOR SPECIFICATIONS BASED ON PRODUCT CODE SUFFIX

